# **Operation Guide 5577**

· Your watch may differ somewhat from the one shown in the illustration.




#### **Crown Operations**

Crown Operations Some water-resistant models (100 meters, 200 meters) have a screw-in crown. When you need to perform a crown operation, rotate it towards you to unscrew it. Then pull the crown out. Avoid applying undue force when pulling. The watch loses its water resistance while the crown is unscrewed. After performing a crown operation, fully screw the crown back in.



If your watch has a rotary bezel... You can rotate the bezel to align its ♥ mark with the minute hand. Then you will be able to tell how much time has elapsed since aligning the ♥ mark.



To adjust the time setting

## When the second hand is at 12 o'clock, pull out the **Crown** to stop it. Rotate the Crown to change the time setting. Push the **Crown** back in on a time signal to resume timekeeping.

### To turn on illumination

Hold down 🛈.

- Note
- Illumination remains turned on as long as () is depressed.
  Illumination will turn off about four seconds after () is released.

#### Illumination Precautions

- Illumination may be hard to see when viewed under direct sunlight.
- · Frequent use of illumination runs down the battery.

#### **Specifications**

Accuracy at normal temperature: ±20 seconds a month Illumination: LED (light-emitting diode)

Battery: One silver oxide battery (Type: SR626SW) and one lithium battery (Type: CR1616) Battery Life: Approximately 3 years on type SR626SW and type CR1616 (assuming one 9-second illumination operation per day)

· Always have both batteries replaced at the same time.

Specifications are subject to change without notice.

### **CASIO**

Note

When changing the time, move the minute hand four or five minutes past your final setting, and then back it up to the setting you want.